



Wheel Fitment Guide Instructions:
350MM Rear Rotor Upgrade(FL5/DE5/FK8)

2017+ Honda Civic Type R (FK8)
2023+ Honda Civic Type R (FL5/DE5)

- 1) Print copy of drawing: Set page scaling to "Actual Size" or "1:1"
- 2) Verify dimensions: using a ruler, verify the horizontal red line is ~108.0mm in width. Then, verify the vertical red line is ~252.0mm in length. If print does not match, correct print scaling
- 3) Glue printed copy to a more rigid paper such as a manila folder or thin cardboard.
- 4) Cut along the thick black outline shown to the right.
- 5) Lay edge of cutout template on inside surface of wheel hub as shown
- 6) While holding the cutout template vertical and on end, rotate around wheel radius. Verify that the edge of the cutout has 4mm+ clearance to hub, spokes, and barrel of wheel

Black outline represents outer profile of rear rotor upgrade. Please allow 4mm (0.16") clearance between outline and wheel spokes

~108.0mm

~252.0mm

Cut Line

Cut Line

Place Against
Wheel Hub

Centerline Align with Center of
Wheel Hub

Place Against
Wheel Hub

Cut Line

Wheel
Hub Bore

~64mm

Note: the wheel hub bore size may be slightly different than shown.

Align wheel hub bore with the centerline shown on cutout.

Rotor Center

Check Template Fitment on Wheel:

- Place the template vertically against the wheel hub. Template shown may not match exact vehicle, for illustration purposes only
- Center template on hub center as shown.
- Check clearance between template and wheel.
- Verify there is 4mm+ clearance between wheel and template.
- If there is contact or insufficient clearance, use spare nuts and washers stacked on the wheel hub to determine the clearance needed.
- Measure the height of the nuts and/or washers used to determine the spacer thickness needed.
- Once the spacer is obtained, check template fitment again with spacer installed on the wheel.

